


TONKEE MACHINERY CO.,LTD



Excavator, bulldozer spare parts



Address: Room 507-509 Zhucun Commerce & trade building, Tianhe, Guangzhou, Guangdong, 510660, China

Email: tina@tonkeeparts.cn

Website: www.partsdic.com

Mobile: +8613250597622

Company Introduction

In the competitive landscape of heavy machinery parts, Tonkee Machinery Co., Ltd. stands as a paragon of reliability and innovation, specializing in premium replacement hydraulic components. Catering to renowned brands such as Kawasaki, Rexroth, Nabtesco, Kayaba, Nachi, Parker, and Doosan, we have carved a niche for ourselves by consistently delivering products that blend cutting – edge technology with unwavering quality.

Our comprehensive product portfolio is a testament to our dedication to meeting the diverse needs of excavator users worldwide. From high – performance hydraulic main pumps that power the most demanding operations to travel motors, swing motors, and main control valves engineered for seamless integration, each item undergoes meticulous design and manufacturing processes. Our hydraulic hammer breakers, too, are built to withstand the harshest conditions, delivering superior performance every time. Leveraging China’s advanced manufacturing prowess while strictly adhering to international quality benchmarks, our products are a fusion of cost – effectiveness and top – tier quality.

What sets us apart is our unparalleled compatibility with a vast array of excavator brands. Whether you operate Caterpillar, Komatsu, Hitachi, Kobelco, Hyundai, Doosan, Volvo, John Deere, JCB, Sany, Xcmg, Sdlg, John Deere or Case excavator equipment, we have the perfect replacement parts. Our team of seasoned experts, armed with in – depth knowledge of excavator mechanics, ensures that each part not only fits flawlessly but also optimizes machine performance. This means you can enhance your equipment’s capabilities without the exorbitant costs and logistical headaches of relying solely on original manufacturers.

At Tonkee, we prioritize customer satisfaction at every stage. Recognizing the urgency of getting your machinery up and running, we have established a robust logistics network. Through sea freight, air freight, rail transport, and strategic partnerships with global couriers like DHL, FedEx, UPS, TNT, and Aramex, we guarantee prompt delivery of your essential parts, regardless of your location. Whether you’re managing a large – scale construction project or conducting routine maintenance, entrust Tonkee with your hydraulic part requirements. Experience the Tonkee difference – where quality, reliability, and exceptional service converge.



Value

Realise customer needs and bring them value,
respect and care for customers



Trust

Build a bridge of communication with trust to
make employees feel at ease and win-win with
customers



Innovate

Keep product advantages with continuous
innovation,
market advantage, enterprise advantage.



Culture

To appoint and train excellent talents, to keep
learning,
Keep growing, constantly challenge ourselves and
create good results together



Hydraulic pumps

Piston pump
Piston motor
Gear pump
Fan motor
Working pump
Steering pump
Transmission pump
For excavator and bulldozers

TONKEE MACHINERY CO.,LTD
www.partsdic.com
+86-13250597622

Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR
			
345D/349D FAN PUMP 295-9426	345D/349D FAN MOTOR 295-9429	330D/336D FAN PUMP 259-0815 10R-8707	330D/336D/340D fan motor 234-4638
Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR
			
345B L/345B II FAN PUMP 155-9248/173-3420	330C FAN MOTOR 191-5611	330C FAN PUMP 283-5992	325C 322C FAN MOTOR 179-9778
Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR
			
980H/980G PISTON PUMP 235-2716	340/352/349/336/345GC 524-0924	414E/416E/422E/428E/434E 350-0666	416E/F/422F/428F/434F 307-3063
Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR	Fit for CATERPILLAR
			
336GC FAN MOTOR 505-5179	966H/966G/972G/972H 161-8919	980G/980H FAN MOTOR 255-6805	352/345GC FAN MOTOR 512-0949

Fit for LIUGONG	Fit for HITACHI	Fit for KOBELCO	Fit for SANY
			

PVD-3B-56P-18G
LIUGONG 907

HITACHI ZAX60-5
PVD-2B-50P

SK75
K3SP36B

XCMG XE35 SANY SY35

Fit for ZOOMLION	Fit for CATERPILLAR	Fit for KUBOTA	Fit for YANMAR
			

A11V075
LONKING 85, LOVOL 85,
ZOOMLION 85

PVD-00B、PVD-0B、PVD-1B

KUBOTA KX15、DOOSAN S17、HITACHI ZX17、SDLG ER616F、KUBOTA 17、SK17、IHI 18NV
、CAT 301.5C CR、BOBCAT E17Z/E20、YANMAR VIO-17、301.7C CR、YANMAR VIO-15、
LOVOL FR18E2-U、302C CR、KUBOTA U20-5、KUBOTA RX306、KUBOTA U30-6
VIO27-5B、SUNWARD SWE25UF、KUBOTA 25、303C CR、YANMAR VIO30-5、YANMAR VIO30-6
、HITACHI U30-5、HITACHI U30-6、HITACHI ZX29、HITACHI ZX27

Fit for HITACHI	Fit for KUBOTA	Fit for KUBOTA	Fit for KUBOTA
			

AP2D28 HITACHI EX60

KUBOTA KX163/165
PSVL2-27CG


KUBOTA U50 KX151 KX161
KYB PSVL-54CG

KUBOTA KX185
KYB PSVL-36CG

Fit for KUBOTA	Fit for CASE	Fit for Kayaba	Fit for VOLVO/KYB
----------------	--------------	----------------	-------------------




PSVL-42CG	AP2D25	PSVD2-17E	PSVD2-21E	PSVL-84 ECR88D
KX121 E303/303.5/E35	CX55 SK55	PSVD2-27E		



K3V63	K3V112	K3V112DTP-HN2F	K3V140DT
-------	--------	----------------	----------



K3V63DTP	K5V160/CAT E330D	K5V160DTP	K5V200DPHTL
----------	------------------	-----------	-------------



K5V200DP	K7V63DTP	K7V125DTP	PSVD2-27E
----------	----------	-----------	-----------



齿轮泵	齿轮泵	齿轮泵	齿轮泵
-----	-----	-----	-----

No.		Model	Brand (PARTSDIC)	Suitable Machine	Weight (KG)	Packing Size (CM)
1		PVD-1B-32CP-9AG5	PARTSDIC	HITACHI ZX-29	22	34*20*21
2		PVD-1B-32CP-8AG5	PARTSDIC	HITACHI U-30-6	22	34*20*21
3		PVD-1B-32CP-11G5	PARTSDIC	HITACHI U-30-5	22	34*20*21
4		PVD-1B-24BP-8AG5	PARTSDIC	YANMAR VIO-27-5B	26.5	37*28*20
5		PVD-1B-31BP-8AG5	PARTSDIC	YANMAR VIO-30-5	26.5	37*28*20
6		PVD-1B-32BP-12G5	PARTSDIC	YANMAR VIO-30-6	26.5	37*28*20
7		PVD-0B-16BP-6AG4	PARTSDIC	YANMAR VIO-17	24.5	37*28*20
8		PVD-0B-18B-5	PARTSDIC	YANMAR VIO-15	23	37*28*21
9		PVD-1B-34P-11G5	PARTSDIC	3-3.5 ton	19.4	34*20*21
10		PVD-0B-18P-6G3	PARTSDIC	LOVOL FR18E2-U	19.4	34*20*21
11		PVD-00B-14P-5G3	PARTSDIC	KUBOTA 15、DOOSAN 17	16	34*20*21
12		PVD-00B-15P-5AG3	PARTSDIC	KUBOTA 17/KOBELCO SK17	16	34*20*21
13		PVD-00B-16P-6AG3	PARTSDIC	IHI 18NV	16	34*20*21
14		PVD-0B-24P-11AG5	PARTSDIC		19.3	34*20*21
15		PVD-0B-24P-8G3	PARTSDIC	KUBOTA 25/CAT ct25	19.3	34*20*21
16		PVD-0B-24P-6G3	PARTSDIC	SUNWARD SWE25UF	19.3	34*20*21
17		PVD-0B-12P-5G	PARTSDIC	BOBCAT E17Z/E20	17.6	34*20*21
18		PVD-0B-21P-6G3	PARTSDIC	KUBOTA U-20-5	19.3	34*20*21
19		PVD-1B-28P-8AG4	PARTSDIC	CAT 303C CR	21.5	34*20*21
20		PVD-00B-18P-6AG4	PARTSDIC	CAT 301.5C CR	16	34*20*21
21		PVD-0B-19P-6G3	PARTSDIC	CAT 302C CR	19.4	34*20*21
22		PVD-0B-17P-6G3	PARTSDIC	CAT 301.7C CR	19.4	34*20*21
23		PVD-1B-32P-11G5	PARTSDIC	HITACHI ZX-27	21.5	34*20*21
24		PVD-15B-32P-9AG5	PARTSDIC	KUBOTA RX306	21.5	34*20*21
25		PVD-15B-37P-11G5	PARTSDIC	KUBOTA U-30-6	21.5	34*20*21
26		PVD-1B-32P-G8	PARTSDIC		21.5	34*20*21
27		PVD-0B-24P-G3	PARTSDIC		19.4	34*20*21
28		SA10VS028DFLR/3	PARTSDIC	XCMG 15/PC30	21	34*20*21
29		1R VSC12N00 1R-VSA12N00	PARTSDIC		21	34*20*21

Fit for Komatsu Excavator

No.	Description	Part number	Suitable Machine
01	Gear pump	705-41-08070	PC10-7/PC15-3/PC20-7
02	Gear pump	705-41-08001	PC20/30-6/PC38UU-1
03	Gear pump	705-86-14060	PC20-5/30-5
04	Gear pump	705-86-14000	PC20-5/30-5

05	PumpAss'y/Main Pump	705-41-08080	PC25-1/PC38UU-2
06	PumpAssy/Main Pump	705-41-02470	PC27MR-1/PC28UU-3
07	Pump Ass'y/Main Pump	705-41-02320	PC27/35MR-1/PC28UU-3
08	PumpAss'y/Main Pump	705-41-02700	PC27/30MR-3
09	Pump Ass'y/Main Pump	705-41-08240	PC28UU/UD/UG-2
10	PumpAss'y/Main Pump	705-41-08100	PC28UU/UD/UG-2
11	Pump Ass'y/Tandem Pump	705-52-10070	PC30-1
12	Gear pump	705-22-21000	PC30-1
13	Gear pump	705-56-14000	PC30-3/PC20-3
14	PumpAssy/Main Pump	704-41-07500	PC35MR-3
15	PumpAss'y/Main Pump	705-41-07180	PC35MR-2/3/PC38UU-3
16	PumpAssyMain Pump	708-3S-04531	PC40MR-1/PC45MRX-1
17	PumpAssy/Main Pump	708-3S-04570	PC40/50/55MR-2/3
18	Gear pump	705-54-20010	PC40-3
19	Gear pump	705-41-08010	PC40-6
20	Gear pump	705-41-08090	PC40-7C/PC50UU-2
21	Gear pump	705-41-02310	PC40/45MR-1
22	PumpAss'y/Main Pump	705-41-01920	PC40R/45R-8
23	PumpAss'y/Main Pump	705-41-07040	45MRX/PC40MR
24	Pump Ass'yMain Pump	705-41-01620	PC50UU/UD/UG/UUM-2
25	Gear pump	705-52-20010	PW60-1
26	Gear pump	705-58-24010	PC60-2
27	Gear pump	705-56-24080	PC60-3/PC60U-3
28	Gear pump	704-24-24401	PC60-5/PC75UU-1
29	P. C. C. Pump/Control Pump	705-40-01370	PC75UD/UU-2
30	Pump Ass'y/Main Pump	705-24-29090	PC75UU/UD-3/78US-5
31	Pump Assy/Main Pump	705-22-30150	PC75-3/PC95R-2/PC110R-1
32	PumpAss'y/Main Pump	708-3T-04610	PC78UU-6
33	PumpAss'y/Main Pump	708-3T-04620	PC78US/PC80MR
34	Gear pump	705-52-20050	PC80-1
35	Gear pump	705-54-20000	PC80-1/PC40-1/PC40-2
36	Gear pump	705-56-34000	PC120-1/2
37	Transmission Pump	705-41-01540	PW128UU-1
38	Gear pump	705-56-24090	PC200-1/PC220-1
39	Gear pump	704-56-24030	PC200-1/PC220-1
40	Pump Assy	705-56-24020	PC200-1/PC220-1
41	Tandem Pump	705-51-10020	PC200/200LC-2
42	Pump Assy/Main Pump	705-24-24420	PC100L/ 120/200/210LC-6
43	Pump assy/Main Pump	705-24-28203	PC200/WA700/PW210-1
44	Gear pump	705-24-28230	PC200/WA800/WA900

45	Pump assy/Main Pump	705-24-26430	PC100/120/300-6/PC400-6
46	Gear pump	705-52-21140	PC600/650-6-7-6K-7K
47	Gear pump	705-52-30011	PC650-1
48	Gear pump	705-52-30010	PC650-1
49	Gear pump	705-51-31060	PC650-3-5/PC750/PC800/1800-6
50	Gear pump	705-52-31070	PC750-6-7/PC800-6-7
51	Pump Assy	705-56-34360	PC1100-6/PC1250-6/PC1250-7
52	Fan Pump	705-21-26050	PC1250-7/PC1100-6

Komatsu Bulldozer Gear Pump Series

No.	Description	Part number	Suitable Machine model
01	Gear pump	07421-71401	D20P/A
02	Pump Assy	705-61-28010	D20P-7A
03	Gear pump	113-15-00270	D21P/31
04	Gear pump	113-15-00470	D21P/D31A-20
05	Gear pump	705-12-32110	D30/31-17/D37-21
06	Work Pump	705-21-28270	D31-18/20/D37-5
07	Work Pump	705-21-26180	D31-20/D37-5
08	Gear pump	705-21-31020	D31/37
09	Gear pump	704-12-30100	D31A
10	Steering Pump	705-11-33013	D31E-17
11	Steering Pump	705-11-33016	D31E-20
12	Gear pump	705-11-20010	D31Q/P/DNP031-3
13	Work Pump	705-52-21000	D40A/40P/40PLL-3-5
14	Steeringing Pump	705-12-32010	D41-3/5/GD405A-
15	Steeringing Pump	705-12-32010	/ 1D-35/ D2405A-
16	Work Pump	705-52-21070	1/GD505A 2 D41A-6/D41E-6/D41P-6
17	Main Pump	705-12-29630	D41A/P/E-6
18	P.T.O Pump	705-41-01370	D41PF-6K
19	Gear pump	705-52-21170	D41P-6/D41E-6/D41E6T
20	Gear pump	705-12-34010	D41S-3/GD705A-4
21	Tandem Pump	07400-30200	D50A/P
22	Gear pump	704-12-38100	D50A-16/18/17/D50P-18
23	Main Clutch Pump	07429-72302	D50A/P
24	Steering Pump	07427-72400	D50A
25	Tandem Pump	07400-40400	D50A/P
26	Main Clutch Pump	07426-71400	D50P
27	Gear pump	07437-71301	D50P/S
28	Steering Pump	07429-71300	D50P

29	Main Clutch Pump	07437-71300	D50P/S
30	Gear pump	07438-67301	D50P/S
31	Pump Ass'y	704-11-38100	D53A-16/18/D58E-1
32	Gear pump	07432-72203	D58/53
33	Gear pump	704-11-38100	D58P-1/D53S-16
34	Steering Pump	07429-71203	D58P/53/57
35	Hydraulic pumpHydraulic Pump	07441-67503	D60/65/70
36	Work Pump	07443-67503	D60/D65
37	Tandem Pun	07400-40500	D60A/P/70
38	Steering Pump	0743072301	D60E/P
39	Power Pump	705-51-20370	D60P/D65E/70-12/D85ESS-2
40	P.C.C.Pump	705-41-01320	D60P/D65E-12/D85ESS-2
41	PC.C.Pump	705-41-01020	D60P/D61EX/PX-12/D68ESD-12
42	Pump Assy	705-41-01200	D61P/65EX/65P/68E-12/D85ES-2
43	Lift/Dump/ Stringng Pump	705-51-20640	D61E-12/D61EX-12/D61P-12/D68DEE-12
44	Power Pump	705-51-20830	D63E-12/D65-15/16/17/D68ESS-12
45	P.C.C.Pump	705-41-01050	D65-12/D85ESS-2/D155A-2A
46	Gear pump	705-11-33530	D65/D70/D70LE-12/D65PX-12U/D85ESS-2A
47	Hydraulic Pump	07441-67502	D65/HD460
48	Gear pump	175-13-23500	D65/355/D85A-21/D135A/ 155A-2/HD200/205-2
49	Lift/Dump/ String Pump	705-51-20800	D65E-12/D65P-12/D85ESS-2-2A
50	Lift/Dump/StrineingPump	705-51-20930	D65E-12/D85ESS-2-2A-3
51	Gear pump	07432-71200	D65S/A
52	Gear pump	07430-72203	D65S
53	Gear pump	07432-71201	D65S/95S
54	Gear pump	705-11-36010	D68ESS-12/D61E-12/D63E-12/HD205-3
55	Gear pump	705-11-36000	D68ESS-12
56	Gear pump	14X49-11600	D68ESS-12/D70LE-12/D65PX-12U/D85ESS-2
57	Gear pump	705-11-40010	D65/65/70-12/D85-2

58	Gear pump	705-11-38010	D70LE-12/D85-2-3/D60P/65P-12E
59	Gear pump	705-11-33210	D70LE-12/D65PX-12U/D85ESS-2A
60	Gear pump	705-11-38010	D70LE-12/540-1B/D85ESS-2/D60P-12
61	Steering Pump	07428-71202	D75S-2
62	Transmidding Pump	705-12-44010	D75S-5/HD785-1/2WA500-3/D155AX-5
63	Work Pump	07443-67103	D75S
64	Hydraulic pumpHydraulic Pump	07443-67100	D75S-2
65	Gear pump	07432-72202	D75S-2
66	Transmidding Pump	07432-71300	D75S
67	Gear pump	07400-30100	D75S-3
68	Main Clutch Pump	07431-11100	D80A/P
69	Water Pump	6865-61-1024	D85
70	Water Pump	68685-61-1024	D85
71	Gear pump	07436-72902	D85A-18
72	Steering Pump	07436-72202	D85A-18
73		705-51-30240	D85P-21A/D135A-1-2
74	Work Pump	705-51-30190	D85A-21/D85E-21/D85P-21
75	Gear pump	07429-72101	D85A/P/65/155
76	Work Pump	705-131-31730	D85A/E/P/21
77	Transmidding Pump	705-21-32051	D85A/85E/85P-21
78	Transmidding Pump	705-21-32050	D85A/85E/85P-21
79	Transmidding Pump	705-21-32050	D85A-21
80	Power Pump	705-51-30660	D85-15/18
81	Work Pump	07444-66103	D85A/80P
82	Work Pump	07444-66101	D85A/80P
83	Gear pump	705-11-38210	D85E-21/D66S-1/D155-5/LW250L-1
84	Transmidding Pump	705-22-38050	D85EX/85PX-15/HD325/405-6
85	Steering Pump	07432-72101	D85/80A
86	Gear pump	07432-71203	D85A/80A/75A
87	Gear pump	07437-72101	D85/155
88	Control valve A	154-15-00142	D85A/D95S-2/D85E
89	Transmidding Pump	07433-71103	D85/155/135A/S
90	Transmidding Pump	07446-66104	D150/155
91	Gear pump	705-55-34580	D155AX-5

92	Work Pump	705-52-30A00	D155-6-6R/D155AX-6-7-8/D155AX-A
93	Work Pump	705-51-30360	D155AX-3
94	Power Pump	705-51-30290	D155AX-3-5/D155AX-5
95	Gear pump	705-22-43070	D155AX-6/7/8
96	Scavenging Pump	705-22-42090	D155A-6
97	Gear pump	705-52-40160	D155A-3/D155A-5
98	Gear pump	17a-49-11100	D155A-3/5
99	Work Pump	07446-66200	D155A
100	Work Pump	07446-66103	D155A-1D155C-1
101	Gear pump	07446-66102	D155A
102	Hydraulic Pump	07440-72202	D155/150
103	Gear pump	07436-66102	D155C-1C
104	Work Pump	705-52-30920	D275A-5-5D ·5R/D275AX-5
105	Work Pump	705-52-30250	D275A-2
106	Gear pump	705-71-440030	D275A-2
107	Gear pump	195-49-34100	D275A/375A
108	Gear pump	195-49-34100	D275A/D375A
109	Work Pump	07448-66500	D355A
110	Work Pump	07448-66200	D355A
111	Work Pump	07448-66108	D355
112	Work Pump	07448-66107(66102)	D355A-3
113	Steering Pump	07442-71802	D355A/C
114	Steering Pump	07442-71102	D355A
115	Transmidding Pump	07438-72902	D355C-3
116	Transmidding Pump	07438-72902	D355C-3
117	Work Pump	07436-66800	D355C-3S/N/D155C-1C
118	Transmidding Pump	07434-72902	D355C-1C
119	Gear pump	07434-72202	D355C-1C
120	Transmidding Pump	07434-72201	D355C-1C
121	Gear pump	198-49-34100	D375A-6/D475A-1/
122	Gear pump	705-58-44050	D375A-3/D375A-5
123	Gear pump	705-58-44000	D375A-2/D575A-3
124	Gear pump	704-71-44060	D375-5
125	Gear pump	705-52-40100	D375A-2/5
126	Gear pump	705-52-40000	D375A-1
127	Water Pump	6162-63-1016	D375A-2
128	Steering Pump	07441-72202	D455A
129	Gear pump	705-12-43030	D455A-1
130	Fan Drive Motor Pump	705-21-43010	D475A-1/2

131	Fan Drive Motor Pump	705-21-43000	D475A-1
132	Gear pump	704-71-44071	D475A-5SD
133	Gear pump	704-71-44050	D475A-3
134	Gear pump	704-71-44012	D475-2
135	Gear pump	704-71-44011	D475A-1S/N
136	Gear pump	704-71-44002	D475A-2
137	Gear pump	705-52-42170	D475A-2
138	Gear pump	705-52-42110	D475A-1/2
139	Gear pump	705-52-42000	D475A-1
140	Gear pump	705-52-40290	D475A-3
141	Gear pump	705-52-40250	D475A-3
142	Gear pump	705-52-40580	D475A-3
143	Fan Pump	705-52-30240	D475A-1/D475A-2
144	Work Pump	705-51-40280	D575A-2-3
145	Work Pump	705-51-40270	D575A-2
146	Work Pump	705-51-40260	D575A-2
147	Gear pump	705-51-40250	D575A-2-3/D575A-3-M
148	Gear pump	705-22-48010	D575A-2/3
149	Work Pump	705-21-46020	D575A-2/3
No.	Description	Part number	Suitable Machine model
01	Tandem Pump	705-51-21000	W20-1/WA30-1/505-1/507-1
02	Steering Pump	705-12-21010	WA30-1/WA30-2
03	Return Pump	705-40-01320	WA30-5
04	Hydraulic Pump	705-51-11020	WA70-1/WR8-1
05	Work Equipment And Stringing Pump	705-12-31010	WA80-3/WA100M-3/WA120-3CS
06	Main Pump	705-11-34100	W90-3
07	Steering Pump	705-11-33100	W90-2
08	Transmission Pump	385-10079282	W90-3.W120-3
09	Transmission Pump	385-10234561	W120-1-2-3.530
10	Steering Pump	705-11-36100	W90-2-3.W120-3
11	Main Pump	705-51-32000	W90-3.W120-3
12	Main Pump	705-11-38000	W180-1.545/540-1/540-B-1/545-1
13	Steering Pump	705-11-36000	W120-2
14	Emergency Pump	704-31-24110	WA100-150-1/WA120/180-3WA380-3MC/512/518
15	Hydraulic Pump	705-52-30960	WA100-5
16	/Main/Steering Pump	705-11-33011	WA100-1WA120-3/WA120-3-3T
17	Transmission Pump	705-11-34060	WA120-1
18	Main Pump	705-11-34011	WA120-1

19	Transmission Pump	705-73-29010	WA100/120/150/180-1
20	Hydraulic Pump/Emergency Steering	705-51-20790	WA120L-3/WA120-3MC
21	Transmission Pump	705-73-30010	WA120-3A/D/WA180-3
22	Lift/Dump/Stringing Pump	705-51-20070	WA180-1.WA300-1
23	Main Pump	705-11-32210	WA150-1/WA320-1LC/WA180-1/FD70-7/D61E-12
24	Lift/Dump Pump	705-51-20180	WA150-1/WA180-3
25	Lift/Dump/Stringing Pump	705-56-34690	WA150-5R
26	Lift/Dump/Stringing Pump	705-57-21010	WA180-3MC
27	Lift/Dump/Stringing Pump	705-51-20150	WA200-1/1C
28	Lift/Dump/Stringing Pump	705-51-20290	WA200-1
29	Lift/Dump/Stringing Pump	705-52-20050	WA200-1cpc80-1
30	Lift/Dump/Stringing Pump	705-51-20640	WA200-1-A
31	Lift/Dump/Stringing Pump	705-56-26081	WA200-5
32	Lift/Dump/Stringing Pump	705-56-26080	WA200-5
33	Lift/Dump/Stringing Pump	705-56-26090	WA200-6/WA200PZ-6
34	Lift/Dump/Stringing Pump	705-56-36090	WA200-6
35	Lift/Dump/Stringing Pump	705-51-20090	WA180-1WA200-1
36	Lift/Dump/Stringing Pump	705-51-20240	WA250-1
37	Lift/Dump/Stringing Pump	705-51-20300	WA250-1
38	Lift/Dump/Stringing Pump	705-13-28630	WA250
39	Steering Pump	704-30-29110	WA250LOC
40	Lift/Dump/Stringing Pump	705-57-21000	WA250-3
41	Lift/Dump/Stringing Pump	705-22-36170	WA250-6
42	Lift/Dump/Stringing Pump	705-38-32030	WA250-6
43	Lift/Dump/Stringing Pump	705-41-04400	WA250-6
44	Lift/Dump/Stringing Pump	705-41-05690	WA250-6
15	Lift/Dump/Stringing Pump	705-56-36040	WA250-5,WA270
46	Lift/Dump/Stringing Pump	705-56-33100	WA250-6
47	Lift/Dump/Stringing Pump	705-56-36082	WA250-6
48	Lift/Dump/Stringing Pump	705-51-20400	WA200-1/WA200-1C
49	Transmission Pump	705-51-20170	WA150/180/200-1/WA250-1/OC
50	Transmission Pump	705-11-30210	WA180-1/WA200-1/WA250-1
51	Lift/Dump/Stringing Pump	705-51-20290	WA250-3
52	Transmission Pump	705-51-20390	WA250-3/WA200-1-A WA150/250
53	Lift/Dump/Stringing Pump	705-55-34090	WA300-1
54	Lift/Dump/Stringing Pump	705-51-22000	WA300-1/WA320-1
55	Lift/Dump/Stringing Pump	705-51-20140	WA300-1/WA320-1
56	Lift/Dump/Stringing Pump	705-51-20280	WA300-1/WA320-1

57	Lift/Dump/StringingPump	705-51-32080	WA300-1/WA320-1R
58	Transmission Pump	705-21-26060	WA320-3
59	Lift/Dump/Stringing Pump	705-55-34160	WA320-3/WA320-3X
60	Transmission Pump	705-51-20480	WA320-3/WA320-3C/WA320-3AP
61	Lift/Dump/Stringing Pump	705-55-24130	WA300/320-1/3CS/WA320-3DZ
62	Lift/Dump/Stringing Pump	705-51-32080	WA320-1/1LC/1R
63	Transmission Pump	705-51-20430	WA320-3CS.WA320-3DZ/WA320-3
64	Lift/Dump/Stringing Pump	705-56-36050	WA320-6
65	Emergency Steering Pump	704-30-32110	WA350-1
66	Transmission Pump	705-11-35010	WA350/380/400/420-1
67	Lift/Dump/Stringing Pump	705-52-30080	WA350-1WA350-0C
68	Lift/Dump/Stringing Pump	705-52-30190	WA350-1M
69	Lift/Dump/Stringing Pump	705-52-30220	WA380-1/WA350-0C
70	Lift/Dump/Stringing Pump	705-56-34180	WA380-1
71	Lift/Dump/Stringing Pump	705-56-30090	WA380-1

No.	Description	Part number	Suitable Machine model
72	Lift/Dump/Stringing Pump	705-11-35010	WA380-1C
73	Lift/Dump/Stringing Pump	705-11-35090	WA380-1/WA420-1
74	Gear pump	705-55-33070	WA380-3
75	Lift/Dump/Stringing Pump	705-55-34180	WA380-3
76	Lift/Dump/Stringing Pump	705-55-34140	WA380-3
77	Lift/Dump/Stringing Pump	705-55-34190	WA380-3
78	Transmission Pump	705-51-20440	WA380-3WA380-3D/WA380-3C
79	Lift/Dump/Stringing Pump	705-55-34190	WA380-3DZ
80	Lift/Dump/Stringing Pump	705-51-30600	WA380-5
81	Gear pump	705-21-39070	WA380-5
82	fan pumpFan Pump	705-21-28270	WA380Z-6
83	Lift/Dump/Stringing Pump	705-55-33080	WA380-5/WA400-5
84	Lift/Dump/Stringing Pump	705-56-34240	WA400-1
85	Lift/Dump/Stringing Pump	705-56-34040	WA400-1
86	Steeringing Pump	704-30-34110	WA400-1WA400-3WA450-3WA470-1
87	SteeringingAnd Switch PumpAssembly	705-51-31170	WA400-5L./WA400-5
88	Lift/Dump/Stringing Pump	705-56-34100	WA420-1
89	Transmission Pump	705-22-40070	WA420-3/450/470-3WA500-1-A
90	/Switch/Stringing Pump	705-52-30360	WA420-3/HD255-5
91	P.C.CLift/Dump/P.C.CPump	705-52-30390	WA420-3WA420-3D

92	/Switch/Stringing Pump	705-52-30560	WA420-3CS
93	P.C.Clift/Dump/P.C.CPump	705-52-30550	WA420-3CS
94	/Switch/Stringing Pump	705-52-31150	WA420-3CS
95	/Switch/Stringing Pump	705-56-30560	WA420-3CS
36	/Switch/Stringing Pump	705-55-33100	WA430-5-W
97	/Stringing/Switch Pump	705-51-30710	WA430-5C
98	Gear pump	705-21-42130	WA430-6
99	/Stringing Pump	705-12-37010	WA450/470-1WA450-1-A
100	/Switch/Stringing Pump	705-12-37040	WA450/470-1/WA450-1-A
101	P.C.Clift/Dump/P.C.CPump	705-12-36010	WA450/470-1/WA450-1-A
102	P.C.Clift/Dump/P.C.CPump	705-12-40040	WA450/470/500
103	P.C.Clift/Dump/P.C.CPump	705-52-20240	WA450/470-1
104	P.C.Clift/Dump/P.C.CPump	705-52-20190	WA450/470-1
105	P.C.Clift/Dump/P.C.CPump	705-52-20100	WA450/470-1/PC60-1
106	P.C.Clift/Dump/P.C.CPump	705-12-40010	WA450/470-1/HD465-2-3
107	/Switch/Stringing Pump	705-14-41040	WA450/470-1/WA450-2

No.	Description	Part number	Suitable Machine model
108	/Switch/Stringing Pump	705-14-41010	WA450-1/470-1WA450-2
109	/Switch/Stringing Pump	705-22-36060	WA450-1-A
110	/Switch/Stringing Pump	705-52-30280	WA450-3/WA470-3
111	P.C.Clift/Dump/P.C.CPump	705-52-40130	WA450-3WA470-3
112	P.C.Clift/Dump/P.C.CPump	705-56-43020	WA450-3
113	P.C.Clift/Dump/P.C.CPump	705-51-30580	WA450-5L
114	P.C.Clift/Dump/P.C.CPump	705-52-30580	WA450-5L
115	P.C.Clift/Dump/P.C.CPump	705-52-30810	WA450-5L
116	P.C.Clift/Dump/P.C.C Pump	705-21-42120	WA450/WA480-6
117	/Switch/Stringing Pump	705-52-20240	WA470-1
118	/Switch/Stringing Pump	705-52-20190	WA470-1
119	/Switch/Stringing Pump	705-52-20100	WA470-1
120	/Switch/Stringing Pump	705-51-20290	WA470-1
121	/Switch/Stringing Pump	705-51-20090	WA470-1
122	P.C.Clift/Dump/P.C.CPump	705-52-40150	WA470-3DZ
123	P.C.Clift/Dump/P.C.CPump	705-52-30280	WA470-3-X
124	Transmission Pump	705-52-40280	WA470-3E
125	P.C.Clift/Dump/P.C.CPump	705-52-30580	WA470-5-W
126	P.C.Clift/Dump/P.C.CPump	705-52-30810	WA470-5-W
127	Break Pump	705-41-07210	WA470-5C
128	Gear pump	705-51-31140	WA470-5S/N
129	P.C.Clift/Dump/P.C.CPump	705-51-30820	WA470-6A/6AS

130	Gear pump	705-55-43000	WA480-3-W
131	Work Equipment Pump	705-35-43640	WA480-5
132	SteeringAnd Switch Pump	705-51-30590	WA480-5W/5L
133	Gear pump	705-51-31150	WA480-5-W
134	Gear pump	704-51-30590	WA480-5-W
135	Return Pump	705-40-01020	WA480-5-W
136	/Lift/Dump Pump	705-22-40110	WA500-1
137	Transmission Pump	705-12-38010	WA500-1/3
138	Steering Pump	705-52-30260	WA500-1
139	Steering Pump	705-52-30130	WA500-1
140	Emerg.Stringing Pump	705-30-36110	WA500-1C
141	Steering Pump	705-52-31130	WA500-1/3
142	Loader Loader Steering Pump	705-56-34130	WA500-1R
143	Stringing Pump	705-12-38011	WA500-3
144	Loader Loader Pump	705-22-44070	WA500-3
145	Loader Loader Pump	705-12-44040	WA500-3
146	P.C.C.Lift/Dump/P.C.CPump	705-52-30490	WA500-3/WA500-3C
147	P.C.C.Lift/Dump/P.C.CPump	705-12-44010	WA500-3
148	P.C.C.Lift/Dump/P.C.CPump	705-22-44020	WA500-3
149	Gear pump	705-52-31230	WA500-3C
150	Gear pump	705-56-34710	WA500-6
151	Trans/lub/Switch Pump	705-58-46001	WA600-1
152	Trans/Lubr/Lev	705-58-46000	WA600-1
153	/P.C.C Lift/Dump/Steering/P.C.CPump	705-56-44000	WA600-1
154	Trans/Lubr/Lev	705-57-46000	WA600-1-A
155	Loader //P.C.C. Loader/.Stringing/P.C.C.Pump	705-58-47000	WA600-1
156	P.C.C.Lift/Dump/P.C.CPump	705-52-31080	WA600-3
157	P.C.C.Lif/Dump/P.C.CPump	705-53-31020	WA600-3/WD600-3
158	Trans/Lubr/Lev	705-53-42010	WA600-3/WD600-3
159	Trans/Lubr/Lev	704-53-42000	WA600-3/WD600-3
160	P. C. C. Torque Converter and P. C. CPump	705-23-30610	WA600-3
161	P.C.C.Lift/Dump/P.C.CPump	705-30-42140	WA600-3C
162	P.C.C.Lift/Dump/P.C.CPump	705-52-40150	WA600-5/D2
163	Trans/Lubr/Lev	705-58-44010	WD600-1
164	/P.C.C Lift/Dump/Steering/P.C.CPump	705-56-46010	WD600-1
165	/P.C.C Lift/Dump/Steering/P.C.CPump	705-56-44001	WD600-1

166	Loader //P.C.C. Loader/.Stringing/P.C.C.Pump	705-56-47000	WD600-3
167	P.C.C.Lift/Dump/P.C.C.Pump	705-22-39020	WD600-3
168	Trans/Lubr/Lev	705-58-46020	WD600-1
169	Trans/Lubr/Lev	705-58-46050	WD600-1
170	Transmission Pump	705-51-12090	WA600-6
171	Transmission Pump	705-55-43040	WD600-6
172	Steering Pump	705-52-40080	WD600-1
173	Trans/Lubr/Lev	705-56-43010	WA700-1R
174	Trans/Lubr/Lev	705-58-43010	WA800-1-2/WA900-1
175	Trans/Lubr/Lev	705-58-45030	WA800-3/WA900-3
176	Trans/Lubr/Lev	705-58-45010	WA800-3/WA900-3
177	Return Pump	705-41-02480	WA900L-3
178	Return Pump	705-40-01041	WA900L-3

No.	Description	Part number	Suitable Machine model
179	Trans/Lubr/Lev	705-58-45040	WA900L-3
180	Loader Loader Pump	705-11-22040	WA1200-1
181	Gear pump	705-21-26180	WA1250-7
182	Gear pump	705-21-26050	WA1250-7

Komatsu Dump Trucks Gear Pump Series

No.	Description	Part number	机型Machine model
01	Hoist Pump	705-11-38110	HD200D
02	Transmission Pump	705-11-29010	HD200D
03	Brake cooling Pump	705-11-36010	HD205-3
04	Steering Pump	705-11-23010	HD205320/4653/HD255/325/605-5/HD405-6
05	/Hoist/Steeringing Pump	705-52-22000	HD205-3
06	/Brake cooling/Transmission Pump	705-22-36060	HD205-3/HD205-5/WA450-2
07	/Brake pump	705-12-36010	HD205-3/HD320-3/HD325-3-5
08	Hoist And Steering Pump	705-52-30360	HD255-5
09	Hoist And Steering Pump	705-14-34530	HD320-3/325-3
10	/Hois/Steering Pump	705-52-30050	HD320-3/HD325-3
11	/Hois/Steering Pump	705-52-30040	HD320-3/HD325-3-5
12	Transmission Pump	07439-66103	HD320-2/HD325-2
13	Transmission Pump	705-12-36011	HD325-5
14	Transmission Pump	705-12-38000	HD325-6
15	/Hois/Steering Pump	705-52-30051	HD325-5-6-6W/HD405-6

16	Transmission Pump	705-22-38050	HD325/405-6
17	Transmission Pump	705-12-40010	HD465-2-3
18	PumpAss'y	705-52-32000	HD465-2
19	Steering HoistAnd Brake Pump	705-12-38211	HD465-3-5-7/HD695-5-7/HM350-1
20	Steering HoistAnd Brake Pump	705-52-32001	HD465-3/HD605-5
21	Torque Converter/Transmission/Brake Pump	705-22-28310	HD465/605-7R
22	PumpAss'y	705-52-31170	HD465/605-7
23	Torque Converter/Transmission/Brake Pump	705-52-31010	HD465/605-7
24	/Hois/Steering Pump	705-56-34630	HD465/605-7
25	Torque Converter/Transmission/Brake Pump	705-95-05140	HD465/605-7E0ZR
26	PumpAss'y	705-95-07100	HD465/605-7E0/7R
27	PumpAss'y	705-95-03020	HD465/605-7E0/R
28	Pump Ass'y	705-95-03021	HD465/605-7EQ/7R
29	Transmission Pump	705-12-44010	HD785-1/2
30	Torque Converter/Transmission/Brake Pump	705-51-42010	HD785-2
31	/Hois/Steering Pump	705-52-42100	HD785-3/5 HD7985-3/5
32	Brake cooling Pump	705-52-42090	HD785-35 HD7985-3/5
33	Torque Converter/Transmission/Brake Pump	705-52-42220	HD785-7
34	Torque Converter/Transmission/BrakePump	705-56-44090	HD785-7
35	Main Pump	705-95-07120	HD785-7
36	Main Pump	705-95-07121	HD785-7
37	SteeringPump	705-11-28110	HD785-/985-3-5
38	Brake cooling Pump	705-95-05130	HM250/300-2
39	/Hois/Steering Pump	705-95-07020	HM250/300-2
40	PumpAss'y	705-95-01020	HM250/300-2
41	PumpAss'y	705-22-39020	HM300-1-1L
42	PumpAss'y	705-52-31180	HM300-1-1L
43	PumpAss'y	705-56-34550	HM300-1-1L
44	PumpAss'y	705-12-38011	HM350-1-1L
45	PumpAss'y	705-52-31210	HM350-1-1L
46	PumpAss'y	705-56-34590	HM350-1-1L
47	PumpAss'y	705-56-33050	HM350-1-1L
48	Brake coolingPump	705-41-07051	HM350/400-1-2
49	PumpAss'y	705-22-40110	HM400-1

50	Pump Ass'y	705-52-31150	HM400-1-1L
51	PumpAss'y	705-56-34490	HM400-1-1L
52	PumpAss'y	705-56-33080	HM400-1-1L
53	PumpAss'y	705-56-33040	HM400-1-1L
54	PumpAss'y	705-95-07040	HM400-2-2R
55	PumpAss'y	705-95-05110	HM400-2-2R
56	PumpAss'y	705-95-07030/31	HM400-2-2R

KOMATSU Hydraulic parts/Components

No.	Description	Part number	Suitable Machine model
01	komatsu Torque converter parts	195-13-11126	D355.SD42
02	komatsu Torqueconverter parts	195-13-11512	D355.SD43
03	komatsu Torqueconverterparts	195-13-12112	D355.SD42
04	komatsu Torque converter parts	195-13-12524	D355.SD42
05	komatsu Torque converter parts	195-13-11654	D355.SD42
06	komatsu Torque converter parts	195-13-12724	D355.SD42
07	komatsu Torque converter parts	195-13-11212	D355.SD42
08	komatsu Torque converter parts	195-13-12122	D355.SD42
09	komatsu Torque converter parts	195-13-11252	D355.SD42
10	komatsu Torque converter parts	195-13-11752	D355.SD42
11	komatsu Torque converter parts	195-13-11005	D355.SD42
12	komatsu Torque converter parts	175-13-21124-25	D355.SD42
13	komatsu Torque converter parts	175-13-21141	D155.TY320
14	komatsu Torque converter parts	175-13-24111	D155.TY320
15	komatsu Torque converter parts	175-13-22524	D155.TY320
16	komatsu Torque converter parts	175-13-21654	D155.TY320
17	komatsu Torqueconverter parts	175-13-21253	D155.TY320
18	komatsu Torque converter parts	175-13-22122	D155.TY320
19	komatsu Torque converter parts	175-13-21213	D155.TY320
20	komatsu Torque converter parts	175-13-21641	D155.TY320
21	komatsu Torque converter parts	175-13-21513	D155.TY320
22	komatsu Torque converter parts	175-13-21220	D155.TY320
23	komatsu Torque converter parts	175-13-22313	D155.TY320
24	komatsu Torque converter parts	175-13-22721	D155.TY320

25	komatsu Torque converter parts	175-13-21692	D155.TY320
26	komatsu Torque converter parts	175-13-21770	D155.TY320
27	komatsu Torqueconverter parts	175-13-21750	D155.TY320
28	komatsu Torque converter parts	195-13-13114	D155.TY320
29	komatsu Torque converter parts	175-13-11810	D155.TY320
30	komatsu Torque converter parts	175-13-21160	D155.TY320
31	komatsu Torque converter parts	175-13-21240	D155.TY320
32	komatsu Torque converter parts	175-13-11720	D155.TY320
33	komatsu Torqueconverter parts	195-13-12711	D155.TY320
34	komatsu Torqueconverter parts	195-13-16100	D155.TY320
35	komatsu Torqueconverter parts	175-13-26401	D155.TY320
36	komatsu Torque converter parts	195-13-13410	D155.TY320
37	komatsu Torqueconverter parts	195-13-13400	D155.TY320
38	komatsu Torque converter parts	175-13-23500	D155.TY320
39	komatsu Torqueconverter parts	175-13-21712	D155.TY320
40	komatsu Torque converter parts	195-13-11261	D155.TY320
41	komatsu Torque converter parts	175-13-21007	D155.TY320

OEM replacement KOMATSU, Caterpillar Valve

No.	Description	Part number	Weight KG
01	komatsu bulldozer Vavle	701-43-24002	110
02	komatsu bulldozer Vavle	701-41-11006	46
03	komatsu bulldozer Vavle	175-41-35002	34.6
04	komatsu bulldozerVavle	T19.15.5	34.6
05	komatsu bulldozer Vavle	175-40-21004	80
06	komatsu bulldozer Vavle	195-40-11600A	11.2
07	komatsu bulldozer Vavle	175-40-00023	15
08	komatsu bulldozer Vavle	700-61-13006	40
09	komatsu bulldozer Vavle	175-49-13800	8
10	komatsu bulldozer Vavle	701-40-51002	5
11	komatsu bulldozer Vavle	701-40-62002	10.5
12	komatsu bulldozer Vavle	700-62-54000	2
13	komatsu bulldozerVavie	175-13-26401	4.5
14	komatsu bulldozer Vavle	175-78-62101	1
15	komatsu bulldozer Vavle	195-63-14001	17
16	komatsu bulldozer Vavle	175-60-29005	334

17	komatsu bulldozer Vavle	175-15-44005	4.8
18	komatsu bulldozer Vavle	154-15-45001	34.8
19	komatsu bulldozerVavle	709-92-27002	50
20	komatsu bulldozer Vavle	700-91-38002	39
21	komatsu bulldozer Vavle	154-60-71300	23.5
22	komatsu bulldozer Vavle	154-45-44001	4.8
23	komatsu bulldozer Vavle	154-40-00082	11
24	komatsu bulldozer Vavle	154-15-35000	34.6
25	komatsu bulldozer Vavle	154-40-10005	60.03
26	komatsu bulldozer Vavle	701-34-11002	81
27	komatsu bulldozer Vavle	701-32-27001	40
28	komatsu bulldozer Vavle	195-13-16100	4.5
29	komatsu bulldozer Vavle	195-13-16401	4.5
30	komatsu bulldozer Vavle	154-15-34000	4.8
31	komatsu bulldozerVavle	702-12-14000	13.6
32	komatsu bulldozer Vavle	702-12-13001	13.6
33	komatsu bulldozer Vavle	23Y-89-12300	37.5
34	komatsu bulldozer Vavle	23Y-89-13400	1.6
35	komatsu bulldozer Vavle	154-40-21120	9
36	komatsu bulldozer Vavle	154-40-13510	7.5
37	komatsu bulldozer Vavle	701-30-51002	5
38	komatsu bulldozer Vavle	701-40-61002	7.8
39	komatsu bulldozer Vavle	701-30-00080	2
40	komatsu bulldozer Vavle	154-63-14001	17.6
41	komatsu bulldozer Vavle	195-61-21230	15.2
42	komatsu bulldozer Vavle	155-60-12500	0.3
43	komatsu bulldozer Vavle	23Y-63J-01000	8
44	komatsu bulldozer Vavle	154-60-21001	305
45	komatsu bulldozer Vavle	16Y-75-10000	34.6
46	komatsu bulldozer Vavle	16Y-76-22000	11.5
47	komatsu bulldozer Vavle	16Y-60-05000	81
48	komatsubulldozer Vavle	16Y-60-11000	40
49	komatsu bulldozer Vavle	701-31-11002	50
50	komatsu bulldozer Vavle	16Y-76-23000	4.5
51	komatsu bulldozer Vavle	16Y-76-20000	5
52	komatsu bulldozer Vavle	16Y-11-30000	5
53	komatsu bulldozer Vavle	701-30-62002	8.5
54	komatsu bulldozer Vavle	16Y-60-11010	9
55	komatsu bulldozer Vavle	144-60-21160	
56	komatsu bulldozer Vavle	144-60-22230	8

57	komatsu bulldozer Vavle	154-49-51100	37.2
58	komatsu bulldozer Vavle	709-62-31103	0.3
59	komatsu bulldozer Vavle	175-60-27300	13
60	komatsu bulldozer Vavle	154-63-14100	
61	Caterpillar Vavle	8P7791	
62	Caterpillar Vavle	9P1533	
63	Caterpillar Vavle	OT12200	
64	Caterpillar Vavle	5S6882	
65	Caterpillar Vavle	4T7598	
66	Caterpillar Vavle	8P1672	
67	Caterpillar Vavle	3T8204	
68	Caterpillar Vavle	3G8078	
69	Caterpillar Vavle	3T8203	
70	Caterpillar Vavle	1P6591	

OEM replacement Caterpillar Pump Parts

Part number	Part number	Part number	Part number
3G2194	3G2239	1555091	1U2671
3G2195	3G2243	1U3506	1U3505
3G2196	3G2717	1U3507	1U3519
3G2197	3G2718	1U3508	1U3952
3G2198	3G2719	1U3513	1U3953
3G2199	3G2720	1U3532	3G1266
3G2200	3G2721	1U2652	3G1267
3G2201	1002870	1U2664	3G1268
3G2233	1002961	1U2665	3G1269
3G2233	1013451	1U2666	3G1270
3G2235	1080502	1U2667	3G1271
3G2236	1243503	1U2668	3G2194
3G2237	1243504	1U2669	3G2195
3G2238	1364815	1U2670	3G2196
2P9239	3P6814	3P6816	9P9610

OEM replacement Kawasaki Gear Pump Series

No.	Description	Part number
01	Kawadaki Gear pump	44083-60750
02	Kawadaki Gear pump	44083-61480
03	Kawadaki Gear pump	44083-60000
04	Kawadaki Gear pump	44083-60740
05	Kawadaki Gear pump	44083-60410
06	Kawadaki Gear pump	44083-60160
07	Kawadaki Gear pump	44081-60010

08	Kawadaki Gear pump	44081-60030
09	Kawadaki Gear pump	44083-20060
10	Kawadaki Gear pump	44083-61590
11	Kawadaki Gear pump	44083-60400
12	Kawadaki Gear pump	44093-60110
13	Kawadaki Gear pump	44093-60390
14	Kawadaki Gear pump	44083-60200
15	Kawadaki Gear pump	44093-60780
16	Kawadaki Gear pump	44083-61510
17	Kawadaki Gear pump	44083-60630
18	Kawadaki Gear pump	44083-61490
19	Kawadaki Gear pump	44093-61180
20	Kawadaki Gear pump	44083-60421
21	Kawadaki Gear pump	44083-61701
22	Kawadaki Gear pump	44093-60971
23	Kawadaki Gear pump	44083-60420
24	Kawadaki Gear pump	44083-60422

Part number	Part number	Part number	Part number
1002870	1U3506	1U2666	1U3952
1002961	1U3507	1U2667	1U3953
1013451	1U3508	1U2668	3G1266
1080502	1U3513	1U2669	3G1267
1243503	1U0532	1U2670	3G1268
1243504	1U2652	1U2671	3G1269
1364815	1U2664	1U3505	3G1270
1555091	1U2665	1U3519	3G1271

(Any references to trademarks, names, descriptions, numbers, and symbols are utilized for reference purposes only. The use of manufacturers' names and descriptions is strictly for reference purposes and does not imply any endorsement or sponsorship.)




MUNICH BAUMA 2019 TONKEE in Germany 07
MUNICH BAUMA 2019 TONKEE in Germany 07




Exhibition Bauma Shanghai 02
Exhibition Bauma Shanghai 02



Exhibition Bauma Shanghai 04
Exhibition Bauma Shanghai 04



Exhibition Bauma Shanghai 06
Exhibition Bauma Shanghai 06



MUNICH BAUMA 2019 TONKEE in Germany 09
MUNICH BAUMA 2019 TONKEE in Germany 09



MUNICH BAUMA 2019 TONKEE in Germany 08
MUNICH BAUMA 2019 TONKEE in Germany 08



Exhibition Bauma Shanghai 05
Exhibition Bauma Shanghai 05



Exhibition Bauma Shanghai 03
Exhibition Bauma Shanghai 03



Exhibition Bauma Shanghai 01
Exhibition Bauma Shanghai 01



Topnotch Machining Equipment

The state-of-art machine tools, machining center, welding robots, automatic a:



Scientific Management System

In product research and development, production and inspection,



JET CHUH

DIRECT MANAGER



PERSONAL PROFILE

I am a construction machinery like excavators, bulldozers, cranes professional who has years of experience handling various roles on sites.

SKILLS & EXPERTISE

1. Strategic planning & team leadership for business growth.
2. Risk control & cross-department coordination to drive profits.

GET IN TOUCH

Address: Room 507-509 Zhucun Commerce & trade building,
Tianhe, Guangzhou, Guangdong, 510660, China
Phone: +8613250597622 Email: info@partsdic.com
Website: www.partsdic.com

CAREER HISTORY

Direct Manager

Tonkee Machinery | April 2016 - present

1. Oversee ops, set sales strategies/targets, manage profit for construction parts.
2. Build sales teams, develop clients, coordinate supply chain-sales links.

Sales Manager

Tonkee Machinery | May 2012 - March 2016

1. Lead sales team, hit sales targets, maintain key clients.
2. Analyze market, report performance, coordinate internal work.





TONKEE Excavator parts Since 2012

